


Instructions for connecting the Electronic Pressure Controller (EPC) to the Pump.

The pump can be used by itself or together with the EPC. Follow these two pictures you can connect them easily.

- 1) Apply Teflon tape to the EPC inlet and connect it to the pump's outlet as showed in **Picture 1**
- 2) Connect the Black(1), White(2) and Green(3) wires to the corresponding number as show in **picture 2**



Picture 1



Picture 2